



## **Beam Sensor**


FI-615

1-877-815-5744


[www.frightideas.com](http://www.frightideas.com)




## Specs and Connections



## BooBox Flex and FlexMax Wiring



## PicoBoo and PicoFX Wiring



## BooBox Flex with Molex Inputs Wiring

