

BooBox FlexMax

OPERATING MANUAL

Firmware Version 1.23

Modified Sep. 15, 2011

Check your Version
See Page 4




6 Oakside Court
Barrie, Ontario L4N 5V5
Tel: 1-877-815-5744 or 905-803-9274
www.frightideas.com

Getting Familiar with your FlexMax	3
Connections and Controls.....	3
Updating the BooBox's Firmware.....	4
Power Supply	5
Selecting your Power Supply	5
Connecting your Power Supply.....	5
Sharing the Power Supply with other Devices	5
Solid-State Outputs	6
About the Solid-State Outputs.....	6
Replacing the Solid-State Driver Chip.....	6
Output Wiring Diagrams and Examples	7
BooBox Output Accessories	8
BooBox Expansion Connector Pinouts	9
Trigger Inputs.....	10
About the Trigger Inputs.....	10
Wiring Diagrams.....	10
Optically Isolating your Trigger.....	11
Audio Connections	12
Line Out Connection	12
Mix In Connection	12
Mix In Microphone Setup	13
Amplified Speaker Outputs.....	14
About the Internal Amplifier.....	14
Two Speaker Wiring Diagram	14
Four Speaker Wiring Diagrams.....	14
DMX.....	16
About DMX.....	16
DMX Connection	16
Typical DMX Chain	17
Setting DMX Channels.....	17
FlexMax DMX Channel Assignments.....	17
FlexMax Operation.....	18
Sounds.....	19
How the FlexMax uses Sounds.....	19
Converting Sounds to MP3.....	19
Copying Sounds to the BooBox's SD Card.....	19
BooBox SD Card Sound File Locations	19
Connecting BooTunes to Add Sound Channnels.....	20
Programming Animation and Settings with the ScareMaster	21
Connecting the ScareMaster.....	21
The Basics	21
Programming DMX Animation.....	22
Advanced Scene Options.....	23
BooBox Setup	24
Troubleshooting	25
Specifications	26

Getting Familiar with your FlexMax

Connections and Controls



CONNECTIONS AND CONTROLS	
Solid-State Outputs	Animation outputs (12 or 24 VDC depending on power supply).
Speaker Outputs	50 watt (25x2) stereo amplified audio output.
Audio Status LEDs	These LEDs illuminate when sound is playing. One represents the left channel of the BooBox's MP3 Decoder, one the left channel of Mix In.
SD Card Slot	Socket for the SD card which holds the sound and animation.
Line Out	Line-level output of the BooBox's MP3 decoder.
MP3 Vol	Controls the Speaker Output volume of the BooBox's MP3 decoder.
Mix In	Line-level input mixed into the amplified Speaker Output. This audio will not be mixed into the Line Out output.
Mix Vol	Controls the Speaker Output volume of the Mix In audio.
Play Button	Tap to play the input 1 scene, or tap to stop any playing scene.
Trigger Inputs	Optically-Isolated trigger inputs for scene triggering.
DMX In/Out	DMX connector for controlling lighting or any other DMX device.
Power	12-24 VDC power input. Connected internally to the 2.1mm power input.
Servo Outputs	RC Servo outputs. These are controlled with DMX channels 4 and 5.
Power Connector	12-24 VDC power input. Connected internally to the Power terminal block.
ScareMaster Connector	Connection for the ScareMaster animation programmer.
Expansion Connector	Easily control our relay boards or AC Relay packs using this connector.

Updating the BooBox's Firmware

At the heart of the BooBox is its firmware. We are continuously updating this firmware with new features, and fixing any bugs our users may find. These updates are available free from our website, and they're easy to install. Please check our website occasionally to see if there's an update available for your BooBox.

Determining the Current Version of your Firmware

When you first connect a ScareMaster to the BooBox, the ScareMaster will show a screen with its version number.

```
ScareMaster  
v1.21  SN:2041
```

ScareMaster Firmware Version

That will be followed by a screen that shows the model and version number of your BooBox. Your BooBox's version number is shown on the top-right next to the model number, version 1.23 in the example below.

```
FI-216 v1.23  
SD      DMX:00
```

BooBox Firmware Version

Checking for a New Version Online

Updating the BooBox's firmware is easiest using the ScareMaster Combo Update. This will update your ScareMaster at the same time should it have also been updated.

Navigate to <http://www.frightideas.com/support/> in your browser. In the top box you'll see a Combo Update with a table listing the current ScareMaster version, as well as the current version for all the BooBoxes. If the ScareMaster or BooBox version on the website is higher than yours, we recommend updating. It's also a good idea to read the Version History to see what's changed.

Updating Your Firmware

1. Download the Combo Update listed on the web page above.
2. Open the .zip file, inside you should see a bunch of folders starting with "FI-".
3. Insert the ScareMaster's SD card into your computer's SD card reader. Copy all the folders, **except FI-SHOWS**, from the .zip file to the ScareMaster's SD Card. (FI-SHOWS contains all your saved shows and sounds. If you overwrite yours by mistake you will lose all your shows. If you want to erase all your shows and really start from scratch then you can copy this folder too.)
4. Eject the card.
5. If your BooBox needed an update, put the SD card into the BooBox. The PLAY light should blink for up to 30 seconds while it updates.
6. Eject the card and put it back in your ScareMaster. When you power up it will automatically update the firmware if required.

Power Supply

Selecting your Power Supply

The FlexMax requires a 12 or 24 volt DC power supply. When using 24 volts, the power supply **must be regulated**. The Flex does not ship with a power supply, you must purchase your own supply based on the required voltage and current of your outputs. We **highly** recommended using a 24 volt power supply. This will get you the most wattage from the audio amplifier and enable you to use larger solenoids without exceeding the maximum current capacity of the solid-state outputs. It will however require that all the devices connected to your outputs be rated for 24 volts.

Sizing Your Power Supply

To size a supply you must calculate for the worst-case scenario. Add up the wattage for the most outputs that will be on at any one time. If you are using the internal amplifier, add at least 25 watts if you're playing at a moderate volume, or 50 watts if you'll be turning it up really loud. Then add 5 watts for the FlexMax.

So for example, let's say you have 10 x 6 watt 24 volt solenoids, but only 4 are on at any given time, and you want to use the amplifier at a moderate volume.


24 watts (4 x 6 watt solenoids) + 25 watts (amplifier) + 5 watts (FlexMax) = 54 watts
You'd need a 24 volt regulated DC supply rated for at least 54 watts.



DO NOT use unregulated 24 volt power supplies. They will exceed the maximum 24 volt input limit and damage the internal amplifier.


Connecting your Power Supply

The power supply can be connected to the 2.1mm barrel connector or the terminal block.



Sharing the Power Supply with other Devices

The power terminal block and barrel connector are internally connected. This makes it easy to share the power supply with another device provided your power supply has enough wattage to go around.



About the Solid-State Outputs

The solid-state outputs are ideal for reliably controlling relays and solenoids. They cannot be used to directly control A.C. powered or contact-closure devices like a relay can. However, unlike relays, they have no moving parts that will wear out over time. They also have feedback suppression diodes built-in to absorb the nasty noise relays and solenoids release the moment they are turned off.

To use the solid-state outputs reliably you must be mindful of their current limitations. Each output can handle 500mA of current regardless of the supply voltage, this calculates to 6 watts at 12 volts, or 12 watts at 24 volts. This is why we recommend 24 volt supplies, you will be able to use much larger solenoids without exceeding the 500mA limit.

Internal Fuses

In addition to the 500mA per output limit, there are also two internal fuses, one for outputs 1-8, and one for outputs 9-16. These fuses will temporarily open if the sum of the current flowing through either set of outputs is around 1.1A for too long. The fuse will automatically reset once the excessive draw has been removed. This may sound like a limitation, but not really. Most solenoids draw about 5 watts on average, at 24 volts that's 210mA per solenoid. So four valves could be left on continuously without fear of overloading.

Do Not Short The Outputs!

The internal fuses will protect the solid-state driver chips from being overloaded, but they are not fast enough to protect them from direct shorts. Double-check your wiring before you power up. If you see a small puff of smoke or smell something nasty, you may need a new driver chip.


Replacing the Solid-State Driver Chip

If some or all of the outputs are no longer working, or they are all on no matter what you do, the solid-state driver chip likely needs to be replaced.

Buying a New Chip

The driver chip used in the BooBox is a very popular chip used by many manufacturers. We carry them on our website, but they will almost certainly be available at a local electronic component supplier if you're in a jam. You can also purchase them from online suppliers like Digi-Key and Mouser.

The chip's part number is ULN2803A. Various manufacturers make compatible parts with almost identical part numbers, although there may be a few more letters after the A. As long as the chip package is DIP and it looks like the picture below, it will almost certainly work just fine.




Replacing the Solid-State Driver Chip

Replacing the chip is a somewhat delicate process. The best way to learn how to do it correctly is to watch the video on our website. Search for driver chip in the search box and click on the first hit to see the product details and video.

Output Wiring Diagrams and Examples

Controlling D.C. Solenoids and Relays


Use only solenoids or relays rated at the same voltage as your power supply. If your device draws more than the 6 watts at 12 volts or 12 watts at 24 volts then see *Controlling Large Solenoids and Relays*.



DO NOT COMMON YOUR + CONNECTIONS ACROSS OUTPUT BANKS. OUTPUTS 1-8 AND 9-16 ARE FUSED SEPARATELY. MAKE SURE EACH SET OF OUTPUTS USES IT'S OWN + CONNECTION.


Controlling an A.C. Outlet

Solid-state outputs cannot be used to directly control A.C. devices. These must be controlled through a relay as shown below. If you have many of these devices to control, see our Relay Board or A.C. Relay Packs in *BooBox Output Accessories*.



Controlling a Fog Machine

Standard fog machines can be controlled by hacking the remote and wiring the button to a relay. More expensive fog machines can be connected to the BooBox with DMX.




Controlling Large Solenoids and Relays

Devices that aren't compatible with the solid-state outputs can be controlled through a relay. If the device being controlled is a solenoid or relay, it's recommended to install a diode or capacitor across the leads, as close to the device as possible. Use a diode if the device is D.C., or a capacitor if the device is A.C. This will absorb the feedback these devices create when they are turned off and the energy stored in their coil is released. Without this part you may notice quirky behavior in nearby electronics, including the BooBox or ScareMaster.

Recommended Parts

Diodes – Standard 1N4001-1N4004 diode, Radio Shack part numbers 276-1103 or 276-1102.


Caps – 0.1uF capacitor rated for at least 200 volts. Radio Shack part numbers 272-1053 or 272-1051.



BooBox Output Accessories

These output accessories make it convenient to control devices that aren't compatible with the BooBox's solid-state outputs. They connect easily to the expansion connector on the side of the BooBox and instantly mirror the activity on outputs 1 thru 8. Solid-state outputs 1 thru 8 on the BooBox can be used simultaneously with any of these accessories, however they will both turn on and off at the same time.

If you are interested in dimming lighting rather than just turning it off and on see *DMX*.




BooBox Output Accessories		
Relay Boards	FI-324-12 (12 volt) FI-324-24 (24 volt)	Each relay board has four 10 amp relays. Connect up to two in series to get eight relays. Available in 12 or 24 volts, buy the model that matches your power supply.
AC Relay Pack 4	FI-304	Provides four 120 volt A.C. duplex receptacles.
AC Relay Pack 8	FI-308	Provides eight 120 volt A.C. duplex receptacles.

BooBox Expansion Connector Pinouts

The expansion connector is really just another way to connect to the BooBox's solid-state outputs. Rather than connecting a bunch of wires to the terminal blocks, a specifically made wiring harness can be plugged into the expansion connector, effectively making all these connections at once.

We use this connector to make connecting to our BooBox Output Accessories quick and painless. If you'd like to utilize this connector for your own applications, the pinouts are shown below. If you've used a MiniBrick, these pinouts might look familiar.






EXPANSION CONNECTOR PINOUTS	
PIN	CONNECTION
1	Ground
2	Output 8
3	Output 7
4	Output 6
5	Output 5
6	Output 4
7	Output 3
8	Output 2
9	Output 1
10	+ Connection (12 – 24 VDC Fused at 1 Amp)

About the Trigger Inputs

The trigger inputs are used to activate your scenes automatically when a sensor picks up movement. Trigger Inputs are activated when 5 to 24 volts A.C. or D.C. is applied to the input terminals. The inputs are optically-isolated, which means they are electrically isolated from the sensitive electronics inside.


You'll need to supply power to the inputs in order to trigger them, in most cases this power can be "borrowed" from the power terminal block as shown below. This method negates the optical isolation, but for most setups this is completely fine. For complete optical isolation see *Optically Isolating your Trigger*.

Wiring Diagrams



Optically Isolating your Trigger


In situations where the FlexMax is being triggered by another controller on a separate power supply, or by a pushbutton or sensor that's located a significant distance from the controller, it's best to take advantage of the optical-isolation.






Line Out Connection

The Line Out audio connection outputs the audio from the BooBox's MP3 decoder. The audio is at line-level, ideal for connection to most amplifiers and powered speakers.




Mix In Connection

The Mix In is a line-level audio input that allows other sound sources to take advantage of the BooBox's internal amplifier. Any audio on this connector will be mixed with the BooBox's sounds and amplified. Control the amplified volume level of this audio using the MIX VOL controls. This audio will not be mixed into the Line Out connection, only the speaker outputs.



Mix In Microphone Setup

Microphones do not generally output a line-level audio signal like the FlexMax expects to receive at the Mix In input. To use a standard microphone you must use a mixer or microphone pre-amp to amplify the audio to line-level before it is input into the FlexMax.




About the Internal Amplifier

The FlexMax includes a 50 watt Class D stereo amplifier. This thing gets LOUD! If you start hearing the audio cut out or sound distorted before your ears start to bleed, it's likely that your power supply is too small. To take full advantage of this amplifier, the power supply needs to be 24 volts and have at least 50 watts of power.

The amplifier uses efficient high frequency modulation techniques to amplify the sound to such a high level without wasting loads of energy as heat. This is how we can fit it inside the FlexMax without needing the giant heat sinks typically seen on amplifiers at this wattage. This technique does however create interference in the form of high frequency noise. Not to worry, it doesn't affect sound quality, it's well beyond what humans can hear. If you'd like to keep the FCC happy and cut down on this interference, it's recommended to use shielded speaker cables. Connect the shield to the GND pin on the BooBox.


Two Speaker Wiring Diagram

The most common setup. Use only 4 or 8 ohm speakers.




Four Speaker Wiring Diagrams

Four 8 ohm speakers can be connected in parallel. This appears as a single 4 ohm load on each speaker output.



Four 4 ohm speakers can be connected in series. This appears as a single 8 ohm load on each speaker output.



About DMX

DMX is an industry standard control protocol used to control lights, strobes, fog machines, and many other exciting stage and theatre products. The FlexMax can be programmed to output DMX data so you can control any DMX device in sync with the rest of your show.


DMX uses a single cable to transmit up to 512 channels of control information to many DMX devices at once. Think of the DMX cable as a TV cable, a single TV cable has many TV channels running down the wire at the same time, it's up to your TV to tune into the one you want to watch and ignore the rest. Same with DMX, each DMX device must be told which channels you want it to listen to.

Unlike TV's, DMX devices may listen to more than one channel at the same time. A four output dimmer pack will need four channels, one for each lighting channel. A colored LED spotlight might use five channels, one for each color, one for a master dimmer, and one for a strobe rate. You'll need to refer to the device's manual for a listing of its DMX channel assignments. In all cases, the channel setting on the device represents its starting channel. So if we assign our dimmer pack to start at channel 5, that would mean its output 1 = channel 5, output 2 = channel 6, output 3 = channel 7, and output 4 = channel 8.

If you have multiple DMX lights or devices and you want them to do the same thing, start them at the same DMX channel. This way they'll all be tuned into the same information and therefore do the same thing without having to program each one separately. This can save a lot of programming time.


DMX Connection

You'll need to connect your DMX devices to the DMX terminals on the BooBox. The easiest way to do this is to cut the appropriate end off a DMX cable, strip it, and connect the wires into the DMX 1, 2, and 3 terminals. Look carefully at the DMX connector on the cable, the pin numbers are marked on each pin, make sure the wires from each pin connect to the appropriate terminals on the BooBox.



Typical DMX Chain

A typical DMX chain with a few dimmer packs might look like this. Every DMX device has an input and output, additional devices are always connected to the output of the last device.



DMX Terminators

If your DMX chain is really long (100 feet or more), or if you start noticing wonky behavior, you might need to terminate your DMX chain. Terminators are really just a 120 ohm resistor. They absorb the signal at the end of the cable so it doesn't reflect and cause interference. Terminators can be purchased on our website if required, or make your own with any 120 ohm resistor.

Setting DMX Channels

If you were using one 4 Channel DMX Dimmer Pack, you'd want to set it to start listening at channel 4. This would mean it's listening to channels 4,5,6, and 7. Any additional dimmer packs would be set to the next available channel, which in this example would be channel 8.


The starting channel for many DMX devices is set using dip switches with each little switch having a numeric value. The first switch has a value of 1, second is 2, third is 4, fourth is 8, fifth is 16, etc. Turn on the switches that add up to the value you want. So for example if you want DMX channel 4, turn on only the third switch. For DMX channel 6, turn on both the second and third switch.

FlexMax DMX Channel Assignments

The FlexMax reserves the first three DMX channels for itself (five if you are using the servo outputs). If you want to control a DMX device, set its starting channel to 4 if you are not using the servo outputs, or 6 if you are.

FlexMax DMX Channels	
DMX CH	Description
1	Scene and sound command
2	Outputs 1 – 8
3	Outputs 9 – 16
4	RC Servo A
5	RC Servo B

The FlexMax is essentially a show controller. In the case of the FlexMax, a show consists of different scenes of digital animation and sound that are played upon a trigger, timer, or end of another scene. The available scenes on the FlexMax are Ambient, and Input 1 thru Input 8. Each of these scenes can be empty, contain one scene, or contain multiple scenes that are indexed through with each trigger. It is not necessary to have a scene programmed in every location. A very simple show may only have one Input or Ambient scene.



Show Diagram

Scene Length

The length of the animation always dictates the length of a scene. If you have a sound that's four minutes long, and program one minute of animation, you will only hear one minute of that sound when the scene plays. If you want the entire sound to be heard, you must program animation for the entire length. This also applies to scenes that have sound but no animation, common for ambient scenes. You must still record blank animation for the entire length of the sound.

Ambient Scene

The Ambient scene loops continuously while the controller waits to be triggered. This scene is most often blank, or used to set the stage for an upcoming Input scene. Often there is only audio in this scene, but more advanced scenes may also control any of the digital or DMX outputs.

When any of the Trigger Inputs are activated, this scene will be interrupted and the corresponding input scene will begin. Once the input scene is complete, the ambient scene will restart at the beginning. For a little variety, program up to 8 different scenes and sounds in Ambient. Each one will be looped indefinitely until an input scene is triggered, upon return the next ambient scene will be looped.

Input Scenes 1 - 8

These scenes are triggered when the corresponding trigger input is activated. By default, the scene will be played to completion, ignoring any other trigger inputs. Once completed, the ambient scene will be played if it exists, otherwise the unit will sit idle. If the trigger input is still activated once the scene completes, the scene will loop.

To add a little variety, program multiple scenes and sounds for your inputs. Each time the trigger is activated the next scene will be played. The first scene is always INX-0, second INX-1, and so on up to -7. Use as few or as many of the additional scenes as you like, the BooBox will automatically loop back to the -0 scene when the last scene is played.

Scene Options

Each scene's behavior can be customized to behave differently depending on your requirements. See *Advanced Scene Options* for more information.

Sounds

How the FlexMax uses Sounds

When a scene is started, the FlexMax will look for an MP3 sound file to play with the scene. Which sound file it plays is based on the file's location and filename. If a sound file is not found, the animation will be played with no sound.

The length of animation you program into a particular scene is what dictates the length of play. So for example if you have a four minute sound file, but only programmed one minute of animation into that scene, the sound file will only play for 1 minute.

Converting Sounds to MP3

Sounds must be in MP3 format for them to play on the FlexMax. Sounds can be converted using iTunes, or our favorite, Audacity. Audacity is a free sound editor and converter for Mac and PC. Google "Audacity" and give it a try. Make sure you also download the Lame MP3 encoder listed on their page.

Copying Sounds to the BooBox's SD Card

To copy the sounds to the BooBox's SD card you'll need an SD card reader. Most laptops and some desktops have these built in, or you can buy a USB version for a few bucks at a local computer store. We also sell them on our website if you can't find one locally.

Once you insert the SD card into the reader you'll see a folder named FI-216. Inside that folder is another set of folders, one for each scene the BooBox can play. Sounds need to be copied into one of these scene folders. If you're only using one sound per scene, you can just copy the sound into the appropriate folder. If you're using multiple sounds per scene, each sound will need to be renamed to match the scene for which you'd like it to play. See the table below for a list of sound filenames.

BooBox SD Card Sound File Locations

If you're using more than one sound per scene, your sound file will need to be renamed as per the table below.



Some computers will not show the .MP3 file extension as we are showing it below. Many computers will just show "000". Take note of the existing sound file we placed in each scene folder. If it has the .MP3 extension then make sure yours does too, if it doesn't then don't add it to your filename.

BOOBX FLEXMAX SOUND FILES		
FOLDER	FILENAME	DESCRIPTION
\FI-216\AMBIENT\	000.MP3	Sound file for Amb-0
	001.MP3	Sound file for Amb-1
	...	
	007.MP3	Sound file for Amb-7
\FI-216\INPUT1\	000.MP3	Sound file for In1-0
	001.MP3	Sound file for In1-1
	...	
	007.MP3	Sound file for In1-7
...		
\FI-216\INPUT8\	000.MP3	Sound file for In8-0
	001.MP3	Sound file for In8-1
	...	
	007.MP3	Sound file for In8-7

Connecting BooTunes to Add Sound Channels

The BooBox can playback a stereo audio track for each scene. This provides two separate audio tracks, a left and right channel. Some scenes or props need additional audio channels that start and stop at the same time as the BooBox. In the past this was accomplished by connecting one or more of the BooBox's outputs to the inputs of additional MP3 players. Pulsing the output at the start of the animation triggered the MP3 players. This required one output per audio track, plus another if you wanted to be able to stop the sound before the end. This method wasted outputs, and programming animation was a pain.

The Right Way


With the latest firmware (v1.23 for BooBox, v1.10 for BooTunes), multiple BooTunes can be synchronized to a BooBox using the DMX output. This will allow the BooBox to automatically start and stop the BooTunes in sync with its own scenes. The BooTunes will automatically play the correct sound file, ambient sound for ambient mode, Input 1 sound for Input 1, etc. No fancy programming, no loss of outputs, it just works.

BooTunes Setup

Copy your sounds to the correct folders on the BooTune's SD card as you would normally. Inside the FI-408 folder, create an empty folder named `_SLAVE` (underscore, followed by SLAVE). This will tell the BooTunes you want it to be a slave to a connected BooBox.


Wiring

The three DMX pins on the BooBox must be connected to the corresponding pins on all BooTunes. Pins 2 and 3 **MUST** be connected using a twisted pair. You can find twisted pairs inside CAT5 cables used for computer networking. Pin 1 can be connected using any type of wire. We'll often use one of the remaining pairs in the CAT5 cable for pin 1, just twist the two wires from an extra pair together, essentially making one wire.




Programming Animation and Settings with the ScareMaster

Connecting the ScareMaster



The FlexMax requires your ScareMaster be at firmware version 1.20 or higher. The version number is shown briefly in the bottom-left corner the moment the ScareMaster powers up. If you don't have at least version 1.20, you can download the latest version from our website's *Product Support* section.

The Basics



Idle Mode

Once the ScareMaster connects you should see a screen similar to the one above. At this point the ScareMaster is in IDLE mode and you are in full control of the BooBox's outputs. There is no audio in IDLE mode, only when you are playing or recording a scene. Press PLAY to playback the current scene, or press REC to start recording.

Controlling Outputs 9-16

When the ScareMaster is first connected you are controlling outputs 1-8. To control outputs 9-16, hold the REC button until you see the screen display *Outputs: 1-8*. While still holding REC, press the UP and DN buttons to toggle between Outputs 9-16 and 1-8, then let go of REC.

Recording a Scene

Press REC to start recording, whatever you do on the outputs will be recorded. As you record, the timer in the bottom-right corner shows your scene position in minutes:seconds. Press REC again to stop recording.

Playing a Scene

Press PLAY to playback the current scene. Press PLAY again to stop it or let it stop automatically when it reaches the end.

Erasing a Scene

Make sure all 8 outputs and both sliders are enabled, and then tap REC twice. Essentially all you are doing is recording a very short empty scene.

Selecting a Scene

On the screen you should see the current scene you are editing in the bottom-left corner. "In1-0" is input 1's first scene, to select another scene, hold the PLAY button for a few seconds then use the A slider to scroll through the available scenes. The current length of the scene is shown in the bottom-right corner as you scroll through. Let go of PLAY when you see the scene you'd like to edit. In most cases you want to make sure the B slider is all the way down so that the number after the dash is 0. See FlexMax Operation for more details on this feature.

Recording Complicated Scenes

You can hold ENABLE and tap the output buttons to disable various outputs from recording. This way you don't have to program all the outputs at once. Once you are finished recording an output, disable it, then on the next recording pass it will play back rather than record.

Saving your Scenes

Once you are happy with your scenes you must save them to the BooBox. You can edit multiple scenes and only save at the end, you do not have to do this step for each scene. The quickest way to do this is to hold the ENABLE button and tap REC. Alternatively you can enter the menu and choose Save from there, or use Save As to save to a particular show folder.

If you disconnect before saving, your BooBox will revert back to the scenes it had before you connected the ScareMaster. Use this technique if you really messed up and want to go back to where you started. When you plug the ScareMaster back in it will prompt you if you forgot to save. If you say YES your new scenes will be recovered from the ScareMaster, if you say NO your old scenes will be loaded from the BooBox.

Programming DMX Animation

By default the FlexMax is set to broadcast the minimum number of DMX channels it requires. To control any DMX devices you'll need to increase the number of channels. Increase the number of channels to 3 + the number of channels your DMX device requires, for example, set it to 5 to control two lights, 7 to control four lights, etc.

Increasing the Number of DMX Channels

To increase the number of DMX channels, go into the menu by holding ENABLE and tapping PLAY. Scroll down, select Scene Menu, then scroll down to DMX Channels, press ENTER. Use the UP/DN buttons to increase or decrease the number of DMX channels for this scene. When you're done, tap the left arrow until you are back to the idle screen. You'll need to repeat this step for each scene you want to use for DMX.

Assigning the DMX Channels to the A/B Sliders

Now you must assign a DMX channel to each A and B slider. Hold the REC button for a few seconds, a screen will pop up showing which channels are currently assigned to sliders A and B. Slide A and B up and down to change their assigned channel, let go of REC when you are done.

The sliders should now be outputting DMX data on their assigned channels and controlling the lights. If not, make sure recording is enabled on the sliders, the LEDs above each slider should be on. Holding the ENABLE button and flicking the sliders down then up will enable recording. Make a recording pass to program the first two channels. If you have more than two channels, hold REC again, assign the next channel numbers to the A/B sliders and make another pass to program the other two lights. The first two you programmed will play back.

Using Fixed Length Scenes

It's highly recommended to use the Fixed Length scene option when programming scenes with DMX. Without this option enabled you will start noticing lights you recorded on a previous pass turning off or flickering towards the end of your scene. This happens because you recorded a little longer on one pass than another. The channels you recorded before now have blank or corrupt data at the end. Using the Fixed Length option will ensure your scene stops recording automatically at the exact same spot on every pass.

Advanced Scene Options

Each scene has options that can be adjusted to change how the BooBox behaves while the particular scene plays. To get to these settings, go into the menu by holding ENABLE and tapping PLAY, then scroll down to Scene Menu and press ENTER.

Volume L / Volume R (0 – 25, default 25)

Volume of the MP3 decoder's left and right audio channels. Often one channel is used for a character's voice and another for ambient sounds. Being able to adjust these volumes independently allows for easy tweaks without remixing the audio file.

Sound Mode (Auto Ambient, None, default Auto)

Auto – Plays the current scene's sound file if there is one, otherwise silence.

Ambient – Continues to play the ambient sound file during this scene, looping if necessary.

None – Forces silence, same as not having a sound file.

Sound Delay (None – 8.5s, default None)

Delays the start of the sound for up to 8.5 seconds. Useful if you need to animate the opening of a door, or fill a room with fog for a few seconds before the sounds starts.

Fixed Length (None – 31:59, default None)

Forces recording of the scene to stop when this length is reached. Useful when programming DMX or when accurate scene lengths are required.

DMX Channels (2 – 33, default varies)

Number of DMX channels this scene will output.

Pre-Delay (None – 17:00, default None)

Delay from when trigger is tripped to when the scene will start playing. Use this if your sensor is located ahead of your scene or prop and you need a few seconds delay for the patrons to reach the right location.

Post-Delay (None – 17:00, default None)

Time that the Flex will ignore trigger inputs once the scene has finished playing. Use this to prevent the prop from triggering too often.

Interruptible (No, Yes, default No)

Set to YES if you want this scene to be interrupted if another trigger is tripped during playback.

Self-Interrupt (No, Yes, default No)

Set to YES if you want this scene to be interrupted by it's own trigger. Useful if you want the next scene (i.e. IN1-1, IN1-2) to be played if the scene's trigger is tripped again while the scene is playing.

Momentary (No, Yes, default No)

Set to YES if you want this scene to only playback for as long as the trigger is activated, looping if necessary. This is great for actor-controlled props such as electric chairs where you want the actor to have control of exactly how long the prop is activated.

Autoplay Next (No, Yes, default No)

Set to YES if you want the next scene (i.e. IN1-1, IN1-2) to automatically play once this scene is done.

BooBox Setup

The BooBox has some general settings that can be adjusted using the ScareMaster. To get to these settings, go into the menu by holding ENABLE and tapping PLAY, then scroll down to BooBox Setup and press ENTER.

Timer (*None – 31:59, default None*)

Use this to trigger the Input 1 scene on a schedule. The time you set here is the time between shows.

N.C. Inputs (*N.O., N.C., default N.O.*)

Each trigger can be set to respond to a normally open (N.O.) or normally closed (N.C.) trigger.

N.C. Outputs (*N.O., N.C., default N.O.*)

Outputs 1-8 can be set to simulate a normally closed contact. This would invert the behavior of the output, turning it off when it's activated, and on when it's not. This can be useful to keep a light output on by default and have it go off when the scene turns starts.

Servos HiRange (*No, Yes, default No*)

Settings this to YES allows the BooBox to move servos over a 180 degree range rather than the usual 90 degrees. Use this with caution. If the servo cannot handle being pushed this far it may be damaged.

Factory Reset

Use this to reset the BooBox to its factory settings. This will reset most options, for a full reset the SD card must also be cleared and rewritten with fresh files from our website's *Product Support* section.

TROUBLESHOOTING TABLE	
Problem	Solution
Ambient sound is not playing	- Make sure you program animation for the ambient scene. Even if it's blank, sound will not play if there is no animation.
None of the outputs or sounds are working	- Make sure the number of DMX channels on your current scene is at least 5.
ScareMaster LCD says "Detecting BooBox"	- Make sure you have a valid SD card inserted in the BooBox.
All outputs stay on <i>OR</i> Outputs don't work anymore	- The solid-state driver chip most likely needs to be replaced. See our website's <i>Replacement Parts</i> section for more details.
Sound cuts out when using the internal amplifier	- The power supply may be underpowered. Try reducing the volume or swapping out the power supply with one of higher wattage.

SPECIFICATIONS TABLE	
Audio	
Format	MPEG 1 and 2 Layer 3 (MP3)
Quality	Up to 320 kbit/s
Storage Type	SD Card, SDHC (cards 4GB and above) supported
Amplifier	
Wattage	2 x 25 watt
Speakers	4 or 8 ohm (should be rated for at least 100 watts)
Physical	
Length	6.5"
Width	2.5" enclosure only, 3.75" including connectors
Height	1.25"
Weight	0.8 Lbs (0.36Kg)
Electrical	
Operating Voltage	12 - 24 VDC
Power Consumption	Controller: 2.5 watts Amplifier: Up to 50 watts Outputs: Up to 24 watts
Solid-State Outputs	Voltage output = Power supply voltage – 0.5 volts Maximum output is 6 watts at 12VDC, 12 watts at 24 VDC